Instruction Manual

WCE-CLASSIC-SB

UK/EU Backbox Pattress

Contents

# 1.0 What is the WCE-CLASSIC-SB?

The WCE-CLASSIC-SB is a pattress designed to house the WCM keypad. The pattress can be mounted in either a UK or EU backbox.

1.1 Product Image

Front   *Side*

1.2 In The Box

- Internal pattress (Part B)
- Main pattress body (Part A)
- 4 x M3 x 5mm pan head cross screws
- 2 x countersunk M3.5 20mm screws
- WCE-070 plastic coverplate

1.3 Product Requirements

- UK or EU Backbox with 36mm depth
- WCM Keypad
- WLH Coverplate

2.0 Installation Instructions

The WCE-CLASSIC-SB is compatible with a UK or EU backbox. The WCM keypad requires a minimum backbox size of 36mm.

The WCE-CLASSIC-SB is in two main parts, labelled below:

Part A   Part B

1	UK BACKBOX EU BACKBOX	Mount Part B to either a UK or EU backbox using the vertical or horizontal fixings. __NB__ The backbox must be at least 36mm deep.

2
Ensure pry gap is at the bottom
Ensure the WCM is aligned with the pry gap at the bottom of the WCE.

Push the front section of the WCM keypad into Part A.

Once fitted, connect the WCM front section in Part A to the punchdown section inside the backbox via the four-pin connector.

For further instructions on setting up the WCM, see the WCM Instruction Manual. |
| 3 | | Secure Part A to Part B using the four screws. |

4		Line up the coverplate clips to the fixing points on Part B and push down firmly to secure the plate.